


Lafayette

Model SQ-W

[Stock No. 99-03311]



**SQ
Full-Logic
4-Channel
Decoder**

SERVICE MANUAL

CONTENTS

	PAGE
1. SPECIFICATIONS	3
2. ADJUSTMENT PROCEDURES	5
A. Phase Check	5
B. AGC Adjustment	5
C. DC Balance Adjustment	5
D. Gain Control Adjustment	6
E. Separation Adjustment	6
F. Full Logic Adjustment	7
3. BLOCK DIAGRAM	8
4. EXPLODED VIEW	9
5. ELECTRICAL PARTS LOCATION [P.C. Board].....	11
6. PARTS LIST	13
7. SCHEMATIC DIAGRAM	(Separate Sheet)
8. PARTS LAYOUT	(Separate Sheet)

*also, check & clean FUNCTION switch, jacks, replace ON/OFF
pilot lamp & adjust rear channels for proper output.*

1. SPECIFICATIONS

FUNCTIONS	[1] SQ Matrix Decoder with full-logic system [including rear Channel "Vari-Blend"]. [2] Matrix Decoder for systems other than SQ, and for "derived" 4-channel sound from conventional stereo sources. [3] Inputs for discrete 4-channel sources.
INPUT SENSITIVITY [for 1 volt output*]	SOURCE/TAPE INPUTS: 100 mV [High] 500 mV [Low] DISCRETE INPUTS: 500 mV
MATRIX PHASE SHIFT CHARACTERISTIC	90° ± 10° from 50-20,000 Hz.
AGC CHARACTERISTIC [Logic Circuits]	± 3 dB for 35 dB input level change [at 2 KHz].
DECODER CHANNEL SEPARATION [at 2 KHz]	LF to RF: 20 dB. LF to LB: 20 dB. RF to RB: 20 dB. LF to RB: 20 dB. RF to LB: 20 dB. CF to CB: 15 dB. LB to RB: 12 dB.
DECODER OUTPUTS	[1] Front left and right, Rear left and right Outputs [decoded or discrete]. [2] Front left and right, Rear left and right Tape Outputs [decoded or discrete]. [3] 2-channel Tape Outputs.
OUTPUT VOLTAGE*	1 volt at rated input [Master Volume at max].
SIGNAL/NOISE RATIO	70 dB.
HARMONIC DISTORTION	0.2%

CONTROLS SOURCE/TAPE Selector, FUNCTION
MASTER VOLUME, POWER ON/OFF,
INPUT SENSITIVITY SWITCHES [SOURCE /
TAPE].

POWER REQUIREMENTS 105 - 120 volts, 50/60 Hz AC.

DIMENSIONS 14 1/2" W x 3" H x 11 1/8" D.

NET WEIGHT 5 lbs.

* This output voltage is only for "front" channels when decoder is the Composer A or B, modes.
Rear channel output voltage will vary in accordance with the program content of the 2-channel
input source.

BECAUSE ITS PRODUCTS ARE SUBJECT TO CONTINUOUS IMPROVEMENT, THE LAFA-YETTE RADIO ELECTRONICS CORPORATION RESERVES THE RIGHT TO MAKE DESIGN CHANGES OR MODIFICATIONS AT ANY TIME WITHOUT INCURRING ANY OBLIGATION TO INCORPORATE THEM IN PRODUCTS PREVIOUSLY SOLD.

2. ADJUSTMENT PROCEDURES

The adjustments for this unit must be performed in the sequence indicated below:

- [A] PHASE Check
- [B] AGC Adjustment
- [C] DC Balance Adjustment
- [D] Gain Control Adjustment
- [E] Separation Adjustment
- [F] Front Logic Adjustment

SQ-W control settings:

MASTER VOLUME control	Maximum
TAPE-SOURCE switch	Source
H - L SENSITIVITY switch	"L"
FUNCTION switch	SQ FULL LOGIC
POWER	ON

A. PHASE CHECK

1. Apply the output of an audio signal generator [2KHz, 1 volt] to the Left channel SOURCE input jack. Connect a phase meter [or any other device capable of determining phase] between test points (3) and (15) on PC board EPO-146C. Check for a phase difference of $90^\circ \pm 10^\circ$.
2. In same manner, connect the audio signal to the Right channel SOURCE input jack. Connect phase meter between test points (4) and (5) on PC board EPO-146C. Check for a phase difference of $90^\circ \pm 10^\circ$.

NOTE: The output signal voltage at test points (3), (4), (5) and (15) should be approximately 0.3 to 0.5 volts.

B. AGC ADJUSTMENT

1. Apply the output of the audio signal generator [2KHz, 1V] to the Left SOURCE INPUT JACK. Connect an oscilloscope and level meter between test point (7) on PC board EPO-147B and chassis ground. The reading should be 5.0 volts. If necessary, adjust RV1 for this figure.
2. Apply the audio signal to the Right SOURCE input jack and connect the level meter to test point (8) on EPO-147B. Adjust RV2, if necessary, for a 5.0 volt reading.
Connect the level meter to test point (9) and adjust RV3, if necessary, for a 5.0 volt reading. Also check for an undistorted wave shape on the scope.
3. Repeat steps 1 and 2 so that the output at test points (7), (8) and (9) is 5.0 volts ± 0.1 volt.

C. DC BALANCE ADJUSTMENT

1. Connect a high impedance DC voltmeter between test point (6) and (10) on PC board EPO-147B. Adjust RV4 for a zero reading. Then, connect the DC voltmeter between test point (6) and (11). Adjust RV5 for a zero reading.
2. Repeat the procedure in step 1 until the voltage between (6) and (10) and between (6) and (11) is 0 ± 0.1 volt.

D. GAIN CONTROL ADJUSTMENT

1. Use the test set-up shown in Figure 1.




Figure 1. SQ-W Test Set-up

2. Place S1 and S2 switches in the FL positions. The output should be approximately 1 volt. Place the logic switch S3 in the OFF position [test point ① grounded]. The output level should decrease by 3 dB. If not, adjust RV1 on PC board EPO-146C so that the output level change is 3 dB when S3 is switched on and off alternately.
3. In a similar manner, set S1 and S2 to the FR, RL and RR positions, and check for a 3 dB change when the logic switch S3 is switched on and off. Adjust RV2 [FR channel], RV3 [RL channel], and RV4 [RR channel] to obtain the 3 dB difference in level in each case.

E. SEPARATION ADJUSTMENT

In the test set-up of figure 1, set the logic switch S3 in the ON position.


1. Place S1 and S2 switches in the FL positions and note the output level on the meter. Now check the output level when S1 is set to the RL and RR positions — there should be a reduction in level of 18 ± 2 dB in each case. If not, leave S1 in either RL or RR position and adjust RV5 [on PC board EPO-146C] so that a decrease of 18 ± 2 dB is obtained when an RL or RR signal is applied [relative to an FL signal].
2. Place S1 and S2 switches in the FR positions and note the output level. Now check the output level when S1 is set to the RL and RR positions — there should be a reduction in level of 18 ± 2 dB in each case. If this test does not meet the minimum figure required [-16 dB], re-adjust RV5 to ensure a reduction of at least 16 dB when S1 is set to RL or RR. Ideally, you should try to obtain an 18 dB [or greater] level change in the tests performed in both step 1 and 2.

3. Place S1 and S2 switches in the RL positions and note the output level. Now check the output level when S1 is set to the FL and FR positions — there should be a reduction in level of 18 ± 2 dB in each case. If not, leave S1 in either FL or FR position and adjust RV6 to meet this figure.
4. Place S1 and S2 switches in the RR positions and note the output level. Now check the output level when S1 is set to the FL and FR positions — there should be a reduction in level of 18 ± 2 dB in each case. If not, re-adjust RV-6 to ensure that this test produces at least 16 dB level change. Ideally, you should try to obtain an 18 dB [or greater] level change in the tests performed in both steps 3 and 4.


F. FULL LOGIC ADJUSTMENT

1. Place S1 switch in the RR position and S2 in the RL position. Set RV7 to the position in which the separation between RL and RR is just about to decrease.


BLOCK DIAGRAM




EXPLODED VIEW




MODEL SQ-W




ELECTRICAL PARTS LOCATION (P.C. Board)



SQ-W (1) UNIT PC BOARD ASSEMBLY, EPO-146C



SQ-W (2) UNIT PC BOARD ASSEMBLY, EPO-147B



PC BOARD COMPLETE (PUSH SWITCH), EPO-193

PARTS LIST

Symbol No.	Description	Stock No.	Symbol No.	Description	Stock No.
P.T.	(1) Power Transformer	1815-15	R29,30	Carbon Resistor 1/4W 470Ω	
S1	(11) Push Switch	2045-14	R31,32	Carbon Resistor 1/4W 330Ω	
J1	(2) AC Outlet (Brown)	1731-19	R33~36	Carbon Resistor 1/4W 220KΩ	
	(3) AC Power Cord	1256-38	R37,38	Carbon Resistor 1/4W 47KΩ	
	(4) Cord Bushing	4356-20	R41,42	Carbon Resistor 1/4W 27KΩ	
PL1,2,3	(8) Pilot Lamp (CB) 6V34mA	3944-20	R45	Carbon Resistor 1/4W 1KΩ	
J1,4,5	(6) Pin Jack 4P x 3	2239-19	R46	Carbon Resistor 1/4W 1.2KΩ	
J2,3	(7) Pin Jack 3P	2240-19	R47	Solid Resistor 1/2W 10Ω	
F1H	(5) Fuse Holder	1417-19	R48	Incombustible Resistor 82Ω	2762-13
F1	(9) Fuse 1/2 Amp.	4355-20	R49	Incombustible Resistor 180Ω	2763-13
S4a-g	(13) E-Rotary Switch	2048-14	R50,51	Carbon Resistor 1/4W 47KΩ	
	(10) P.C. Board EPO-192	1736-16	R39,40	Carbon Resistor 1/4W 56KΩ	
S2,3	(12) Slide Switch	1877-14	R43,44	Carbon Resistor 1/4W 18KΩ	
	Cable (pin to pin)	1244-38	C1,2	Elyt. Capacitor 1μF 50V	1015-52
R101~104	Carbon Resistor 1/4W 68KΩ		C3	Elyt. Capacitor 47μF 10V	1062-52
R105~108	Carbon Resistor 1/4W 18KΩ		C4,5,6~9	Elyt. Capacitor 1μF 50V	1015-52
C101	Ceramic Capacitor 4700pF	1091-51	C10	Elyt. Capacitor 47μF 10V	1065-52
R109~112	Carbon Resistor 1/4W 2.2KΩ		C11~18	Elyt. Capacitor 4.7μF 25V	1031-52
R113	Carbon Resistor 1/4W 10Ω		C19	Elyt. Capacitor 470μF 50V	
	(35) P.C. Board Complete (PUSH-SW) EPA-0193A	1292-31	C20,21	Elyt. Capacitor 220μF 50V	1097-52
	P.C. Board EPO-0193	1737-16	C22	Elyt. Capacitor 100μF 35V	1082-52
S5a,b	Push Switch	1821-14	C23	Elyt. Capacitor 100μF 16V	1080-52
			C24	Elyt. Capacitor 220μF 50V	1097-52
RF1a~d	Volume Control 4-Gang	1761-11	R52,53	Carbon Resistor 1/4W 68KΩ	
Q1,2	Transistor 2SC-900(F)	2132-17	R54,55	Carbon Resistor 1/4W 56KΩ	
Q3~6	Transistor 2SC-828T	2355-17		Tie Point	
Q7	Transistor 2SC-1096(L)	2160-17		Heat Sink	7605-10
D1,2	Diode F14A	2084-17	(35)	P.C. Board Complete (SQ-W-1) EPA-0146CA	
R1	Carbon Resistor 1/4W 47KΩ			P.C. Board EPO-0146C	1738-16
R2	Carbon Resistor 1/4W 10KΩ		IC1~4	I.C. MFC6043	1022-25
R3,4	Carbon Resistor 1/4W 2.2KΩ				
R5,6	Carbon Resistor 1/4W 330KΩ		Q1~10	Transistor 2SC-945(Q)	2121-17
R7,8	Carbon Resistor 1/4W 680Ω		Q11	Transistor 2SC-900(E)	2195-17
R9,10	Carbon Resistor 1/4W 4.7KΩ		Q16	Transistor 2SA-564(S)	2221-17
R11,12	Carbon Resistor 1/4W 39KΩ		Q17	Transistor 2SC-828(S)	1751-17
R13,14	Carbon Resistor 1/4W 18KΩ		Q18,19	FET 2SK-30(GR)	2265-17
R15	Carbon Resistor 1/4W 33KΩ		D1~4	Diode 1S-1555	1937-17
R16	Carbon Resistor 1/4W 5.6KΩ		Q20	FET 2SK-30(D)	2265-17
R17~20	Carbon Resistor 1/4W 330KΩ		C1,2	Elyt. Capacitor 1μF 50V	1015-52
R21~28	Carbon Resistor 1/4W 5.6KΩ				

Symbol No.	Description			Stock No.	Symbol No.	Description			Stock No.
C3,4	Elyt. Capacitor	4.7μF	35V	1142-52	R64	Carbon Resistor	1/4W	5.6KΩ	
C5	Elyt. Capacitor	47μF	25V	1064-52	R65,66	Carbon Resistor	1/4W	15KΩ	
C6,7	Mylar Capacitor	.047μF	50V	1065-53	R67	Carbon Resistor	1/4W	100KΩ	
C8,9	Mylar Capacitor	.15μF	50V	1073-53	R68	Carbon Resistor	1/4W	150KΩ	
C10,11	Mylar Capacitor	.0068μF	50V	1041-53	R81~84	Carbon Resistor	1/4W	220KΩ	
C12,13	Mylar Capacitor	.0015μF	50V	1027-53	R85~86	Carbon Resistor	1/4W	150KΩ	
C14,15	Mylar Capacitor	.022μF	50V	1055-53	R87,88	Carbon Resistor	1/4W	68KΩ	
C16,17	Mylar Capacitor	.0056μF	50V	1039-53	R89~91	Carbon Resistor	1/4W	3.9KΩ	
C18,19	Mylar Capacitor	.0012μF	50V	1026-53	R92,93	Carbon Resistor	1/4W	120KΩ	
C20,21	Mylar Capacitor	.0056μF	50V	1039-53	R94,95	Carbon Resistor	1/4W	27KΩ	
C22~29,32,33	Elyt. Capacitor	1μF	50V	1015-52	R96	Carbon Resistor	1/4W	22KΩ	
C34,35	Ceramic Capacitor	.5μF	12V	1117-51	R97	Carbon Resistor	1/4W	15KΩ	
C36,37	Ceramic Capacitor	.047μF	25V	1107-51	RV1~4	Potentiometer	5KΩB	3-leg	2682-13
C38	Mylar Capacitor	.022μF	50V	1055-53	RV5,6	Potentiometer	20KΩB	3-leg	2553-13
R1,2	Carbon Resistor	1/4W	150KΩ		RV7	Potentiometer	50KΩB	3-leg	2555-13
R3~6	Carbon Resistor	1/4W	1.2KΩ			Tie Point			
R7~14	Carbon Resistor	1/4W	4.7KΩ		(36)	P.C. Board Complete (SQ-W-2) EPA-0147BA			
R15,16	Carbon Resistor	1/4W	47KΩ			P.C. Board	EPO-0147B	1697-16	
R17,18	Carbon Resistor	1/4W	22KΩ			Q1~3	Transistor	2SC-828(S)	1751-17
R19,20	Carbon Resistor	1/4W	2.7KΩ			Q4~9	Transistor	2SA-564(S)	2221-17
R21	Carbon Resistor	1/4W	3.3KΩ			Q10~15	Transistor	2SC-900(E)	2195-17
R22,23	Carbon Resistor	1/4W	4.7KΩ			Q16,17	FET	2SK-30(O)	2010-17
R24,25	Carbon Resistor	1/4W	6.8KΩ			Q18	FET	2SK-30(GR)	2265-17
R26,27	Carbon Resistor	1/4W	22KΩ			D1~51	Diode	1S-1555	1937-17
R28,29	Carbon Resistor	1/4W	27KΩ			C1~3	Mylar Capacitor	.0022μF 50V	1031-53
R30,37	Carbon Resistor	1/4W	2.2KΩ			C4~6	Ceramic Capacitor	470pF 50V	1070-51
R38,39	Carbon Resistor	1/4W	2.7KΩ			C7~9,10~12	Tantal Capacitor	1μF 35V	1594-58
R40,41	Carbon Resistor	1/4W	22KΩ			C13~20	Mylar Capacitor	.01μF 50V	1046-53
R42,43	Carbon Resistor	1/4W	3KΩ			C21,22	Elyt. Capacitor	.1μF 25V	1000-52
R44,45	Carbon Resistor	1/4W	24KΩ			C23,24	Ceramic Capacitor	.068μF 12V	1162-51
R46,47	Carbon Resistor	1/4W	18KΩ			C25	Mylar Capacitor	.018μF 50V	1052-53
R48,49	Carbon Resistor	1/4W	15KΩ			C26	Mylar Capacitor	.022μF 50V	
R50,51	Carbon Resistor	1/4W	33KΩ			C27	Mylar Capacitor	.0082μF 50V	1044-53
R52,53	Carbon Resistor	1/4W	56KΩ			C28,29	Mylar Capacitor	.0022μF 50V	1031-53
R54,55	Carbon Resistor	1/4W	47KΩ			R1~3	Carbon Resistor	1/4W 47KΩ	
R56	Carbon Resistor	1/4W	2.7KΩ			R4~6	Carbon Resistor	1/4W 220KΩ	
R57	Carbon Resistor	1/4W	100KΩ			R7~18	Carbon Resistor	1/4W 887Ω	
R58	Carbon Resistor	1/4W	3.3KΩ						
R59,60~62	Carbon Resistor	1/4W	15KΩ						
R63	Carbon Resistor	1/4W	120KΩ						

Symbol No.	Description			Stock No.
R19~24	Carbon Resistor	1/4W	270KΩ	
R25~30	Carbon Resistor	1/4W	6.8KΩ	
R31~33	Carbon Resistor	1/4W	27KΩ	
R34~39	Carbon Resistor	1/4W	1.8KΩ	
R40~45	Carbon Resistor	1/4W	100KΩ	
R46~48	Carbon Resistor	1/4W	120Ω	
R49~51	Carbon Resistor	1/4W	180KΩ	
R52~63	Carbon Resistor	1/4W	15KΩ	
R64~67	Carbon Resistor	1/4W	39KΩ	
R68~75	Carbon Resistor	1/4W	33KΩ	
R76~83	Carbon Resistor	1/4W	220KΩ	
R84~87	Carbon Resistor	1/4W	620KΩ	
R88~91	Carbon Resistor	1/4W	56KΩ	
R92,93	Carbon Resistor	1/4W	120KΩ	
R94,95	Carbon Resistor	1/4W	220KΩ	
R96,97	Carbon Resistor	1/4W	150KΩ	
R98	Carbon Resistor	1/4W	68KΩ	
R99,100	Carbon Resistor	1/4W	33KΩ	
R101	Carbon Resistor	1/4W	18KΩ	
R102	Carbon Resistor	1/4W	15KΩ	
R103	Carbon Resistor	1/4W	120KΩ	
R104	Carbon Resistor	1/4W	8.2KΩ	
R105	Solid Resistor	1/2W	2.2MΩ	
RV1~3	Potentiometer	30KBΩ	3-leg	
RV4,5	Potentiometer	10KBΩ	2-leg	2596-13
R04a	Carbon Resistor	1/4W	27KΩ	
R06,07	Carbon Resistor	1/4W	220KΩ	
R08	Carbon Resistor	1/4W	330KΩ	
C30	Mylar Capacitor	.0056μF	50V	1039-53
	Tie Point			
	MECHANICAL PARTS			
	Chassis			1763-80
	Cage			1764-80
	Bottom Plate			1765-80
	Lamp Holder (A) (Tape Source)			9084-10
	Lamp Holder (B) (Power)			9085-10
	Foot			4074-20
	Frame for Push Button			9048-10
	Push Button (Power)			1973-18


Symbol No.	Description	Stock No.
	Push Button (Tape Source)	1870-18
	Knob (Volume/Function)	1975-18
	Lamp Holder (Rubber)	5092-20
	Indicator Jewel (Plastic)	5196-20
	Indicator (Blue)	5193-20
	Stud for P.C.B. Mount	9086-10
	Serial Number Label	9087-10
	Cord Clamper	7706-10
	Escutcheon Assy	1766-80
	Instruction Manual	1863-30

Lafayette RADIO
ELECTRONICS
CORPORATION

111 Jericho Turnpike, Syosset, L.I., New York 11791


KDSQW***XX

Printed in Japan




SQ-W


Full Logic



IC SQ Decoder Circuit



SCHEMATIC DIAGRAM OF MODEL SQ-W



FUNCTION	1 2 CHANNEL	2 COMPOSER A	3 COMPOSER B	4 SQ FULL ~MC	5 DISCR
	J1	J2	J3	J4	J5

Lafayette

RADIO
ELECTRONICS
CORPORATION

111 Jericho Turnpike, Syosset, L.I., New York 11791

